



Maintenance of Tech-Wood Decking

General

Tech-Wood Decking is developed as a maintenance free product for covering of terraces, boardwalks, balconies, galleries, pontoons etc. In these situations Tech-Wood is exposed to all types of weather.

In general, for these situations Tech-Wood does not need any maintenance, provided that Tech-Wood is installed in the proper way with sufficient ventilation and the maximum point-load is not exceeded. For a proper installation please see our Installation Instructions Decking.

Cleaning of Tech-Wood Decking

The upper surface of Tech-Wood can be cleaned. Moss, fungus and other dirt can easily be removed with a high pressure cleaner or brushed away with hand-warm water. It is possible to add soap-like cleaning additives to the water.

Under no circumstances the use of hot water is allowed! Tech-Wood also strongly prohibits the use of organic solvent, strong acid or lixivium!

Burning marks due to cigarettes and persistent dinner (grease) spots can be removed with a wire-brush or alike, followed by brushing away with hand-warm (soap) water.

Chewing gum or other sticky substances should by means of scraping or brushing be removed, followed by cleaning with hand-warm (soap) water.

Under no circumstance the use of deep freezing techniques is allowed